



PEACOC® 360
Spooling Patch Panel
Quick Installation Guide



Spooling Fiber Patch Panel
(Primary Panel)



FRONT SIDE (Patching)



REAR SIDE (Spool Cable Storage)



Scan this Code for Complete Installation Guide

PEACOC® 360 Spooling Patch Panel Quick Installation Guide



This guide covers instructions for:

- Rack Installation
- MPO Cable Pay-out Operation
- PEACOC 360 Rear MPO Cable management and setup

A RACK INSTALLATION



1

Put 1 screw on each side of the Rack plate



2

Take the Patch Panel to the rack and place Panel's mounting bracket above the screws



3

Put 1 additional screw on each side of the mounting Bracket then tighten to secure in place

B MPO JUMPER CABLE PAY-OUT OPERATION



1

Take off the rear Panel cover



2

From the rear side, select the desired cassette



3

Grasp the pull tab of the MPO adapter holder and pull downward to remove it.



1
Push the rear lock sideways then pull out the spool cassette half way until the rear lock re-engage.



2
Take the outer-end of MPO jumper and pay-out the cable up the desired length

C PEACOC 360 REAR MPO CABLE MANAGEMENT AND SETUP




1

Take out the inner end MPO cable from the top of the spool



2

Route the Inner end MPO Cable from the top of the spool going out of the spool cassette



3

Rotate the spool to align the arrows labelled on the top of the spool and cassette




4

Push the lock until an audible sound "clicks" to hold the spool and cable in place




5

Partially insert the cassette back into the chassis




6

Retrieve the MPO adapter holder with the connected fan-out and the inner end of the MPO jumper.



7

Connect the MPO to the Adapter, then reattach the MPO adapter holder to the rear of the spool cassette



8

Secure the MPO cable on the rear cable hanger for organized cable management.



9

Repeat the process for the remaining cassette. Once completed, reattach the rear cover to the chassis.